HUFCOR OPERABLE WALL – OPERATING INSTRUCTIONS

OMNI DIRECTIONAL PANELS: (Single panels with double rollers). This system has a parking area set off the main track line.

1. In the open position the panels will be stacked in the parking area.
2. To close the wall move the first panel onto the main track line, ensuring that the large bulb seal is on the leading edge.
3. Move this panel into the selected close position. Locate the handle into the waist high seal activator on the trailing edge. A half anticlockwise turn will engage both top and bottom seals.
4. Move the balance of the panels into the linking closed position and engage the top and bottom seals as previously explained.
5. The handle must now be inserted into the face of the closure panel and turned into the extend direction. This turning must continue until the bulb seal on the trailing edge of the lever closure are reasonably compressed. You should now be in a position to stand back and view a closed wall, sealed at the top, bottom, sides and intermediate joints. No gaps or light rays should be visible at any of these abutments.
6. To open the wall simply reverse the closing process.

THE PAIRED PANEL SYSTEM: Panels are generally hinged in pairs. Three panels are linked if there is an odd number. There is no off set parking area. The panels are merely stacked in pairs against the end walls. It is recommended to stack equal quantities on either end of the opening. The operating procedure is generally typical to that of the Omni Directional. We will therefore highlight only the different procedures.

1. When stacking away, push the panels from the rear edge of the trailing panel – i.e. panels are parallel with the top track. Close the panels only when near the stacking wall.
2. To activate the top and bottom seals the operating handle must be inserted into the trailing edge of the rear panel. The mechanism is linked from the rear to the leading panel and the seals will engage simultaneously. Do not at any time insert and engage the handle in the linking stiles.

GENERAL NOTES FOR BOTH OMNI AND PAIRED SYSTEM

IFUBA PRODUCTS (Pty) Ltd 10 Northgate Place, Red Hill Durban, P O Box 40220 Red Hill 4071
Tel: 031-533 6400 Fax: 031-533 6401 Website: www.ifuba.co.za E-mail: info@ifuba.co.za
Ifuba Products Gauteng Regional and Export Northlands Business Park, Angus Mini Unit 5, Angus Crescent
29 New Market Street, Northriding, Johannesburg Tel: 011 704 7411 Fax: 011 462 0079

Directors : M J Todd (Managing) M G L Dlamini (Sales) Registration No: 2008/004983/07

When opening it is important that the top and bottom seals have been retracted before the panels are moved. Moving the panels with the seals still in the engaged position can cause damage to the floor, ceiling and the operating mechanism.

1. Before opening or closing walls ensure that all furniture is at least 600mm clear from either side of the wall. Damage to the panel facings or furniture can be costly.
2. The Hufcor operable wall system is extremely well engineered and generally responds well to gentle handling.